




キャンバス・アーバン エックス

CANVAS URBAN X 取扱説明書

INSTRUCTION MANUAL



この取扱説明書は、ご使用になる前に必ずお読みください。

ご使用になる前に

このたびは、弊社製品をお買い上げいただき、誠にありがとうございます。

この取扱説明書は、ヘルメットの正しい取扱方法について説明しております。

ご使用前には必ず最後までこの説明書をお読みいただき、お読みの後は、当説明書を大切に保管していただきますよう、お願いいたします。

ヘルメットは、いかなる事故にも絶対安全という訳ではなく、万一の際に危険の度合いを減らす装備の一つで、安全の一要素としてご理解のうえご使用ください。安全快適なバイシクルライフを楽しむためにも、以下の注意事項をよくご理解いただきますようお願いいたします。



警告


- このヘルメットは「自転車専用」です。オートバイやその他の用途には絶対に使用しないでください。
- 国で定められている交通規則に必ず従ってください。

正しい位置でヘルメットを装着する

ヘルメットを前から後ろにかけて水平になるように着用してください。このときにヘルメットの先端がまゆ毛のすぐ上でない場合は、正しく装着できていません（装着の際は鏡を見ながら調整してください）。また、あごひもの長さやアジャストロック（あごひも調整具）の調整もヘルメットを正しくかぶるうえで大変重要な部分です。当説明書の該当項目をよくお読みのうえ、正しくかぶってください。




正しいかぶり方の例



前から後ろにかけて水平になるようにかぶる



誤ったかぶり方の例



ヘルメットは正しい位置で正しくかぶり、あごひもを正確に締める事で、はじめてヘルメット本来の安全性能を発揮します。ヘルメットは走行前にしっかり正しく装着しましょう。

警告 下記の内容は必ずお読みください。

▲「あごひもは必ずしっかり締めてください。」

あごひもを締めなかつたり、締め方が緩かつたりすると、万一転倒した時などに脱げてしまい、頭を守ることができず非常に危険です。また、ヘルメットと頭の間には何もかぶらないようにしてください。ヘルメットがずれたり、落ちるおそれがあります。

▲「大きな衝撃を受けたヘルメットは外観上に損傷がなくても、ご使用にならないでください。」

ヘルメットはシェル及び衝撃吸収ライナーが潰れることで、衝撃エネルギーを吸収します。大きな衝撃を受けたヘルメットは、既にライナーが潰れていることが多く、そのまま使用すると再度衝撃エネルギーを吸収できず非常に危険です。外観に傷がなくても、使用しないでください。

▲「ヘルメットの改造および分解は絶対にしないでください。」

ヘルメットに穴を開けたり、内部の衝撃吸収材を削ったり、また、あごひもなどは絶対に改造しないでください。ヘルメット本来の性能が発揮できなくなり非常に危険です。

▲「ヘルメットのお手入れは薄めた中性洗剤でふき取るようにしてください。」

ガソリン・シンナー・ベンジン・熱湯（50℃以上）や、塩水等は絶対に使用しないでください。

▲「ヘルメットのペイントは絶対にしないでください。」

衝撃吸収ライナーは、塗料や熱の影響により材質が侵され衝撃吸収力が低下する場合がありますので、ペイントは絶対におやめください。

▲「ヘルメットは大切に取り扱いってください。」

ヘルメットは丈夫だからといって、床等に放り投げたり、上に座つたりしないでください。その度に衝撃を吸収するため、衝撃吸収力が低下します。万一のために大切に取り扱いってください。また、乗車時に頭を保護する目的以外には使用しないでください。

▲「ヘルメットの保管について」

ヘルメットは直射日光の当たる場所への長時間の放置、自転車の上や車の中および、暖房機のそばなど、高温（50℃以上）の場所に長時間放置しないでください。ヘルメットに使われている材質等が変質して、性能が低下します。

ご注意


❶「長期間の日光照射によるシェルの変色について」

ヘルメットのカラーによっては、長期間日光を浴びることにより、シェル表面の色調が変色する場合があります。

❷「マット（つや消し）カラーについて」

マットカラーは表面処理の都合上、あらかじめ貼付されているステッカーをはがすと、表面のマット（つや消し）処理がはがれる事がありますので、ステッカーは絶対にはがさないでください。またお客様がご購入後にご自身で貼付したステッカーを再度はがし取る場合も、同様のことが考えられますので、ステッカーを貼付される際は十分にご注意ください。


部位名称ともくじ



警告	02
1 ワンタッチバックル (あごひも留め具)	04
2 「あごひも」と「アジャストロック (あごひも調整具)」	04
3 アジャスター (頭周調整具)	05
4 インナーパッド (内装)	06
5 フロントバイザー	07
(別売) 補修用パーツ/オプションパーツについて	08
English	10~

1 ワンタッチバックル(あごひも留め具)

ワンタッチバックルは、頭にしっかりヘルメットを固定するための重要な装置ですので、確実にとめましょう。



⚠️ 警告: ●ワンタッチバックルは、必ず最後まで(カチッと音がするまで)きっちり押し込んでください。押し込みが不完全ですと、万一転倒した際にワンタッチバックルが外れてしまい、大変危険です。


2 「あごひも」と「アジャストロック(あごひも調整具)」

ご使用前に必ず試着しましょう!

あなたの頭にぴったりフィットするよう、あごひもの長さは必ず調整しましょう。長さ調整は、ワンタッチバックルを締めるとき、指が1~2本入る程度が一般的です。ご使用前に必ず試着を行い、「あごひも」の長さや「アジャストロック」の位置、「アジャスター」の締め具合などを適度に調整し、頭にぴったりフィットするようにしてください。

※「アジャスター」の調整については「3 アジャスター」をご覧ください。

あごひもの長さ調整




⚠️ 警告:

- あごひもは、左記以外の通し方をするとう、あごひも自体が滑り抜けてしまい、ヘルメットが脱げてしまうおそれがありますので、正確に通してください。
- ワンタッチバックル(差し込む側)の表裏を間違えると、あごひもが緩んで固定が出来なくなりますので、もしワンタッチバックルを完全にあごひもより取り外した場合は、取り付ける際、ワンタッチバックルの方向にご注意ください。
- あごひもは正しくしっかり締めてください。万一転倒した際に大変危険ですので、必ずしっかり締めてください。


アジャストロックの調整

ワンタッチバックル(あごひも留め具)をとめ、しっかり顔の側面に合うように「アジャストロック」の高さを調整します。左下図Aのように耳の下に「アジャストロック」があることを確認し、耳の部分が緩い、またはきつい場合は「アジャストロック」を移動させて高さを調整します。



アジャストロック

アジャストロックの移動方法



アジャストロック補修対応パーツについて

アジャストロックが破損した場合は「アジャストロックセット-06」が代用できます。

アジャストロックセット-06

3 アジャスター(頭周調整具)

「アジャスター」は、ヘルメットのズレやブレを抑えるために、ヘルメット後頭部に装備された調整パーツです。あなたの頭にピッタリフィットさせ、しっかりホールドするようにアジャスターを調整しましょう。

アジャスターの調整方法

アジャスターのダイヤルを適度にゆるめてからヘルメットをかぶり、ヘルメットの前側を押さえながら、適度に締めてください。(下図参照)




緩める

ダイヤルを左へ回す
アジャスターが広がる

締める

ダイヤルを右へ回す
アジャスターが締まる


前を押さえながらダイヤルを回す



ヘルメット前部を押さえながら、ダイヤルを回して適度に締めます。

⚠️ ご注意: アジャスターを調整する際、毛髪が絡まないようご注意ください。


アジャスターの角度を変える(上下3段階)



- ①アジャスター後側の固定部を抑えながらアジャスター本体を手前に引っ張って外す。(図1、2)
- ②外した固定部をお好みの高さに付け替えることにより、角度が3段階調整できます。(図3)

❗ご注意: 固定部を取り外す際は、ゆっくり外してください。ねじったり無理に引っ張ったりすると破損の原因となりますのでご注意ください。

4 インナーパッド(内装)



- 取り外しかた
フロントパッド、トップパッド、スウェットパッドは面ファスナーで取り付けられています。ゆっくり引っ張ると取り外せません。
- 取り付けかた
フロントパッド、トップパッド、スウェットパッドは左図の位置に取り付けます。

❗ご注意: インナーパッドを取り外す際は、面ファスナーが剥がれないようにゆっくり引っ張って取り外してください。

インナーパッドのお手入れについて


汗などで汚れたインナーパッドは、取り外して洗うことができますので、定期的にお手入れすることでインナーパッドを清潔に保てます。

インナーパッドを洗う場合は、水もしくはぬるま湯（35℃以下）にごく少量の洗髪用シャンプーもしくは家庭用中性洗剤を入れ、やさしく手もみ洗いを行ってからよくすすいでください。


洗い終わったら乾いた布などで水気をやさしく取り除き、直射日光の当たらない風通しのよい場所で陰干しを行ってください。

5 フロントバイザー

この製品は、状況やお好みにより、フロントバイザーを脱着できます。



①ヘルメットに付いているトップパッド、フロントパッドを取り外します。



②トップパッド、フロントパッドが装着されていた箇所に当パーツを取り付けます。このとき取り付け箇所にしっかり押し付けます。

⚠️ ご注意: 走行中に脱落するおそれがありますので、正しく取り付けられているか確認してください。



キャンバスインナーパッドセット

カラー：ブラック



キャンバスバイザー

カラー：ブラック



アジャスターバンドセット-11

カラー：ブラック



アジャスターバンドセット-11用スウェットパッド

カラー：ブラック



アジャストロックセット-06

※このアジャストロックは工場出荷時に本体に装着されているアジャストロックとは異なり、交換専用のパーツになります。



重要です!!

Kabutoでは、ヘルメットを快適にご使用いただくために、各種パーツをご用意しております。

ご購入の際は、お使いのヘルメットに適合した補修パーツをお選びください。

パーツ各種の詳細は、弊社カタログ
もしくはホームページに掲載のパー
ツリストをご覧ください。

! **ご注意:** パーツをお買い求めの際は、お使いのヘルメットのモデルをよくご確認のうえ、販売店などへご注文ください。

CANVAS URBAN X

INSTRUCTION MANUAL

ENGLISH

NOTES BEFORE USE

Thank you for purchasing the Kabuto helmet.

This instruction manual provides information on the correct wearing of the helmet. Before use, make sure to read and follow this manual all the way through carefully. After reading, kindly store this manual safely.

The helmet does not guarantee absolute safety in any accident. It is one of the safety measures that may reduce the severity of danger in case of an accident. We kindly request that you understand the following precautions and warnings before enjoying your riding.

⚠ WARNING


- This helmet is for bicycle use only. Do not use this helmet for motorcycle riding or any other activities.
- Please obey all traffic rules.

Wearing Helmet Properly

Wearing the helmet horizontally from front to back. Make sure the front edge of the helmet is just above your eyebrows (Adjust it by using the mirror). To wear the helmet properly, the length of the chin strap and the position of the adjustment lock must be set correctly. Follow the instruction below carefully and wear the helmet properly.


How to wear helmet properly

Correct



Wear helmet from the front to the rear horizontally.

Wrong



The helmet will only exhibit its intended safety performance when worn correctly in the right position and when the chin strap is fastened accurately. Be sure to wear your helmet securely and properly before starting your ride.

WARNING Be sure to read these instructions.

- This helmet is designed for bicycle use only. Never use the helmet for purposes or activities other than bicycle riding.
- Do not wear anything in between your head and the helmet.
- The helmet should be worn in such a way that it protects your forehead, with the edge just above your eyebrows, and never pushed far over the back of your head. Wear the helmet so it is level from front to back.
- No helmet can protect the wearer against all injuries or foreseeable impacts.
- Before riding a bicycle, make sure to adjust the helmet so that it fits your head correctly. The strap should be positioned not to cover the ears, the buckle positioned away from the jawbone, and the strap and buckle adjusted to be both comfortable and secure.
- Your helmet is effective as protection only when it is worn properly. You should try different sizes to choose the proper size for you with which you feel secure and comfortable on your head at time of purchase.
- Please handle the helmet with care. The helmet is designed to absorb shock by partial destruction of the liner and its damage may not be visible. **DO NOT** sit on it, drop it on the floor or otherwise cause impact.
- If subjected to a severe impact, the helmet should be discarded and destroyed.
- Wipe the helmet with common ph-neutral detergent diluted with clear water. Never use any petroleum, thinner, benzene, hot water above 50°C/122°F or saline water.
- Do not leave the helmet in the direct sunlight or where the temperature may surpass 50°C/122°F such as in a car or near a heater, and/or avoid leaving in a humid place for a long time. Doing so will affect the materials and the performance of the helmet will diminish.
- Do not paint the helmet. Paints may reduce the original protective performance of the helmet considerably.
- Do not modify the helmet. In order to fully maintain the performance of the helmet, do not attempt to take it apart or change it in any manner that involves making holes in it or cutting it (or any of its parts) other than as recommended by the manufacturer.
- This helmet should not be used by children while climbing or doing other activities when there is a risk of strangulation/hanging if the child gets trapped with the helmet.

THE EFFECTS OF THE DIRECT SUNLIGHT


Do not leave the helmet in the direct sunlight.

The outer color of the shell may be changed.

CAUTION FOR MATTE COLOR PRODUCT

Matte processing on the surface of this product could be peeled off if the attached sticker is removed from the surface. To prevent this, never remove the sticker. The same problem may occur also when other sticker are attached and removed. If you attach stickers on the product, please be aware of the risk.


Part Names



WARNING	12
1 Strap Buckle	14
2 Chinstraps/Adjustment lock	14
3 Adjuster	15
4 Linings	16
5 Front Visor	17
Helmet parts	18

1 Strap Buckle

The strap buckle is important for secure fitting. Make sure to fasten the strap buckle firmly.



! WARNING

- Make sure to fasten the strap firmly. It is dangerous to ride a bicycle without fastening the strap.
- If the strap buckle is not fastened (ie, you don't hear it click), or if it is fastened loosely, the helmet may come off in an accident, leading to death or serious injury.

2 Chinstraps/Adjustment lock


Adjust the strap to fit your head. It generally should have space to fit in 1 to 2 fingers horizontally when the strap had been fastened properly.

Try on your helmet before riding. Make necessary adjustments such as the length of the chin strap, the position of the Adjustment lock, and the tightness of the adjuster, to ensure a perfect fit on your head.

See: **3 Adjuster** for how to adjust the Adjuster

Adjusting the length of the strap

! WARNING



- Make sure to follow these instructions for adjusting the strap. Otherwise, the strap may become loose and the helmet may come off.
- If the strap buckle is inserted upside down, the strap will be loose and the helmet will not fit your head firmly. If the strap buckle is removed from the strap completely, make sure to place it back in the correct direction.


Adjusting the position of the Adjustment lock

Fasten the strap buckle and adjust the Adjustment lock so they could be placed firmly on the side of your face. Position the Adjustment lock under your ears, as shown in image **A**. Adjust the height of the Adjustment lock to fit the strap neither too loose nor too tight.



Adjustment lock

How to change the Adjustment lock position



About adjustment lock replacement parts

If the adjustment lock is damaged, it can be replaced with the "Adjustment Lock set-06."

3 Adjuster

Adjuster is the mechanism at the rear of the helmet to hold the helmet from wobbling and moving on your head. Fit the helmet onto your head, and adjust the mechanism so that the helmet holds your head securely.

How to use

Place the helmet on your head in the correct position, hold the front of the helmet against your head and turn the dial to loosen or tighten your helmet.




Loosen

Turn the dial to counterclockwise.

Tighten

Turn the dial to clockwise.




Hold the front part and turn the dial.

⚠ CAUTION

Be careful with your hair, especially long hair, so it does not get tangled in the Adjuster.


To change the angle of the adjuster



- ① Pull out the adjuster by following fig.1 and fig.2.
- ② The angle of the adjuster could be switched in three positions as shown in fig.3.

! CAUTION Pull slowly when removing the fixed part. Please note that twisting or pulling on this part with excessive force may damage it.

4 Linings



- **Removing the inner pads**
The front pad, top pads and sweat pad are attached with hook-and-loop fasteners and can be removed by pulling on them slowly.
- **Attaching the inner pads**
Attach The front pad, top pads and sweat pad in the position shown in the diagram to the left.

! CAUTION When removing the inner pad, pull it off slowly so that the hook and loop fastener does not come off.

How to clean linings

Linings are removable and washable.


Keep linings clean by washing periodically.

Use warm water (35°C/95°F or cooler) with small amount of hair shampoo or ph-neutral detergent. Hand wash them gently and rinse thoroughly.


Dry linings with a dry cloth after washing, and leave them in a shaded and well-ventilated place. Avoid direct sunlight.

5 Front Visor

Front visor is attachable.



① Remove the top pad and front pad.



② Attach the front visor by replacing the original front pad and top pad. Make sure each parts attached correctly and firmly.

⚠ CAUTION Make sure it is attached correctly, as it may fall off during the riding.

(Sold separately) About replacement parts/optional parts



Canvas Inner Pad set

Color : Black



Canvas visor

Color : Black



Adjuster band set-11

Color : Black



Adjuster band set-11 Sweat Pad

Color : Black



Adjustment lock set-06

This adjustment lock is different from the adjustment lock installed at the factory and is a replacement-only.



Remember!

Before purchasing these parts, please check the parts list to make sure the parts are suitable for your helmet.

Please refer to Parts List on our website for more information about replacement.

<http://www.ogkkabuto.com/>

CAUTION Please check the model of your helmet to make sure you are purchasing a correct lining set.



発売元 株式会社オージーケーカブト
〒577-0016 大阪府東大阪市長田西6丁目3番4号 TEL 06-6747-8031



Kabuto Japan Web Site

www.ogkkabuto.co.jp

Kabuto Global Web Site

www.ogkkabuto.com

SAFETY MEETS STYLE